myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for BOSCH HMB8020. You'll find the answers to all your questions on the BOSCH HMB8020 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual BOSCH HMB8020
User guide BOSCH HMB8020
Operating instructions BOSCH HMB8020
Instructions for use BOSCH HMB8020
Instruction manual BOSCH HMB8020



Installation Instructions
Instuctions d'Installation
Instrucciones de Instalación

Built-in Microwave Oven

BOSCH

Oven Model:
HMB80..

Trim Kit Models:
HMT87.., HMT80..

Your user manual
BOSCH HMB8020

Manual abstract:

Never allow children to play with packaging material. Never modify or alter the construction of the appliance. For example, do not remove leveling legs, panels, wire covers or anti-tip brackets/screws. MICROWAVE SAFETY PRECAUTIONS TO BE OBSERVED BEFORE AND DURING SERVICING TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY (a) Do not operate or allow the oven to be operated with the door open. (b) Make the following safety checks on all ovens to be serviced before activating the magnetron or other microwave source, and make repairs as necessary: (1) interlock operation, (2) proper door closing, (3) seal and sealing surfaces (arcing, wear, and other damage), (4) damage to or loosening of hinges and latches, (5) evidence of dropping or abuse. (c) Before turning on microwave power for any service test or inspection within the microwave generating compartments, check the magnetron, wave guide or transmission line, and cavity for proper alignment, integrity, and connection. (d) Any defective or misadjusted components in the interlock, monitor, door seal, and microwave generation and transmission systems shall be repaired, replaced, or adjusted by procedures described in this manual before the oven is released to the owner. (e) A microwave leakage check to verify compliance with the Federal Performance Standard should be performed on each oven prior to release to the owner. GROUNDING INSTRUCTIONS This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current.
This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded. WARNING: Improper use of the grounding can result in a risk of electric shock. Consult a qualified electrician or serviceman if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded, and: · Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or serviceman install an outlet near the appliance.
English 2 Installation Before you Begin Trim Kits m CAUTION: · · · Trim kits are designed for use only with the Bosch microwave oven models listed in Table 1. For safety, do not alter or modify any part of this kit or oven. Unit is heavy and requires at least two people to lift or move. Trim Kits 30" Cabinet HMT8050 HMT8060 HMT8020 27" Cabinet HMT8750 HMT8760 HMT8720 Microwave Ovens HMB8050 HMB8060 HMB8020 HMB8050 HMB8060 HMB8020 Table 1: Trim kits for microwave ovens. Combination with Wall Ovens Your microwave oven can be installed into a cabinet or wall by itself or above any of the following Bosch wall ovens: HBN33, HBN34, HBN54, HBN85, HBL33, HBL34, HBL54, HBL85.
m Tools and Parts Needed WARNING: To reduce the risk of fire and electric shock, install microwave at least 3/4" above designated oven. Phillips head screwdriver Measuring tape Drill with bits (1/16") English 3 Parts Included Philips head screws (6) Tapping screws (5) Air duct Adhesive tape Fixing bracket (2) Baseplate Faceplate Power Requirements Electrical specifications: 120V, 18A, 60Hz. The outlet must be properly grounded in accordance with all applicable codes. It can be installed in the backwall directly behind the oven. English 4 Cabinet Cutout Dimensions 27" Appliances Instructions are based on standard American cabinets. 30" Appliances Outlet Area 27" Appliances The outlet can be located anywhere within the shaded area. 30" Appliances English 5 Installation Procedure Prepare the Appliance Prepare the appliance according to figures 1-5 1 2 3 English 6 4 . 5 English 7 Prepare Cabinet Cutout Prepare cabinet cutout according to figures 6 and 7. 6 dia. 1/16" a a=b b English 8 7 dia.

1/16" Connect to Electricity Insert plug into three-prong, grounded outlet. See "Power requirements" for electrical specifications. 8 English 9 Install the Appliance Fit the appliance according to figures 9 and 10. 9 10 Note: Do NOT clean decorative trim with abrasive cleaners..

Your user manual
BOSCH HMB8020